

# Understanding dual connectivity

This page explains how dual connectivity works on your Verofy® Move, when you're connected to both Wi-Fi and GPRS.

## **Does the Verofy® Move automatically switch to GPRS when Wi-Fi signal is poor?**

If your Wi-Fi network drops entirely (i.e., your Verofy® Move disconnects from the Wi-Fi) then the Verofy® Move will automatically connect to 4G/3G/GPRS.

If the Wi-Fi network is still up (your Verofy® Move is still showing as connected to the Wi-Fi network) but the Wi-Fi network is very slow/has no connection to broadband, then you will need to disable the Wi-Fi on your Verofy® Move to force it to disconnect and use 4G/3G/GPRS. If you need help to disable the Wi-Fi connection on your Verofy® Move, click [here](#).

---

Revision #7

Created 27 April 2023 09:41:33 by Verofy® Support

Updated 7 May 2024 15:26:33 by Verofy® Support