


# Checking your GPRS settings


This page shows you where to locate the GPRS settings on your Verofy® Move, and make sure you're connected to the right APN.

1. To get started, head to the **Settings** menu from the start up screen and find the Cellular Settings option.


Please note - the **Cellular Settings** option you'll need might be situated in a different place in the Settings menu to the below guide if you've already logged into your Verofy® Move.




2. Once you've done this, you'll see the Mobile Network screen. Ensure that the options are toggled on as follows. Once you've checked this, press the drop down arrow to expand the **Advanced** options.



3. Once you can see the **Advanced** settings, scroll to the bottom of the page and select **Access point names**.



4. You'll see a few different APNs available. You'll need to ensure the APN **m2m.tns.prod1** is the one which is toggled on (highlighted below). If you don't see this APN in the available list, you may need to add it. Click [here](#) for instructions on how to add the APN.



5. Once you've ensured this APN is toggled on, the Verofy® Move should successfully connect to 4G/3G if you're in a signal with GPRS signal.

Please note, if you have also connected your Verofy® Move to a Wi-Fi network, it will use Wi-Fi as the default. For more information about the Verofy® Move's capability to switch between Wi-Fi/GPRS, click [here](#).

**That's how to check your GPRS settings!**

---

Revision #9

Created 28 April 2023 10:58:06 by Verofy® Support

Updated 7 May 2024 15:23:46 by Verofy® Support