

Verofy® Move overview

This page shows you where to find the power and volume buttons on your Verofy® Move, as well as the charging port.


Contactless reader
Mag stripe reader
A920Pro
Scan button
Power button
Volume up
Volume down
verofy
Charging port
Card reader


Printer lid latch
Camera/Torch
Charging pin points for cradle
Battery compartment switch

Revision #22
Created 31 May 2023 08:38:27 by Verofy® Support
Updated 28 July 2025 16:19:49 by Verofy® Support