# Adjusting your settings to streamline one sale to the next

We know how important it is for your Verofy® Move to make things quick and easy for you during busy periods and that's why we have the **Sale Default** option.


This option streamlines your sales process, by returning to the **Enter amount** screen after each sale, saving you unneccessary clicks.

To enable it, follow the steps below.

1. Head to the **Settings** menu from the main menu screen and select the **App Settings** option.





2. Enable the **Sale Default On** option, then press the back button at the top left of the Verofy® Move screen.




3. Select the **Home** menu, then select **Sale.**




4. Enter the amount of the sale using the keypad. When you've entered this, press the green tick. Complete the transaction as normal and once this is done, your Verofy® Move will return to the **Enter Amount** screen - ready for the next transaction!




If you need any support with this change on your Verofy® Move, **contact us** and we'll be happy to help!

---

Revision #3
Created 31 October 2025 17:52:50 by Verofy® Support
Updated 4 November 2025 17:33:50 by Verofy® Support