


Adjusting your settings to streamline one sale to the next

We know how important it is for your Verofy® Move to make things quick and easy for you during busy periods and that's why we have the **Sale Default** option.

This option streamlines your sales process, by returning to the **Enter amount** screen after each sale, saving you unnecessary clicks.


To enable it, follow the steps below.

1. Head to the **Settings** menu from the main menu screen and select the **App Settings** option.




2. Enable the **Sale Default On** option, then press the back button at the top left of the Verofy® Move screen.

Image not found or type unknown




3. Select the **Home** menu, then select **Sale**.

Image not found or type unknown



4. Enter the amount of the sale using the keypad. When you've entered this, press the green tick. Complete the transaction as normal and once this is done, your Verofy® Move will return to the **Enter Amount** screen - ready for the next transaction!

Image not found or type unknown



If you need any support with this change on your Verofy® Move, [contact us](#) and we'll be happy to help!

Revision #3

Created 31 October 2025 17:52:50 by Verofy® Support

Updated 4 November 2025 17:33:50 by Verofy® Support