Checking connection

This page shows you how to identify when your Verofy® Move is connected to GPRS.

If your business doesn't have WiFi or you to need to be able to take payments on the go, your Verofy® Move can connect to 4G/3G.

> Your Verofy® Move should always be dispatched with the SIM already set up and ready to transact.

If your terminal is successfully connected to GPRS, you'll see the signal bars with a **4G** or **3G** to the left of the bars (as you see in the image below).



If there is no connection established, you'll still see the signal bars but instead of the 4G/3G, you'll just see the letter R in a white circle (as you see in the image below).



If you don't see either **4G** or **3G**, click **here** to learn how to check your GPRS settings.

It's as easy as that! You've checked if you are connected.

Revision #12
Created 27 April 2023 15:36:18 by Verofy® Support
Updated 3 November 2025 12:22:29 by Verofy® Support