



Logging into your Verofy® Move

This page shows you how to login to the Verofy® Move. Contact us on 0330 460 4672 if you can't find your login details, they will have been sent to you via email.

1. When your Verofy® Move arrives, you'll turn it on and be greeted by the login screen. To get started, select the **Verofy Plus** app on screen.



2. Enter your User ID and Password.



The login screen features the 'verofy' logo at the top. Below it is a 'Welcome' heading and a prompt to 'Please enter user credentials'. There are two input fields: 'User ID' and 'Password'. At the bottom is a numeric keypad with digits 1-9, 0, a red 'X' button, a yellow back arrow button, and a green checkmark button.

We recommend changing your password as soon as you've logged in to maximise security. For instructions on how to change your password, visit the [Changing your password](#) page.

3. Once you've entered the User ID and Password, you'll see the Home screen.



The Home screen displays the 'verofy' logo, the date 'THU 27TH APRIL', the user role 'Manager', and the ID 'ID: 1234'. It also shows 'Last Report: 26/04/2023'. The main area contains a grid of eight transaction management buttons: Sale, Refund, Pre-Auth, Completion, Test Acquiring Connection, Card Not Present, Reprint Manager, and Reversal. At the bottom is a navigation bar with 'HOME', 'ADMIN', and 'SETTINGS' icons.

That's it! You've logged in. Your Verofy® Move comes with a SIM card as standard so you can start transacting straight away. If you need to connect to Wi-Fi, [click here](#).

Revision #34

Created 27 April 2023 10:40:40 by Verofy® Support

Updated 6 June 2024 09:34:41 by Verofy® Support